


Smart Siren

USER MANUAL

M420-2Ever1.2




*Please read the user manual carefully before operation.
The guide pictures are for reference only.

PRODUCT DESCRIPTION

Introduce a smart siren to your smart home. When an alarm is triggered in your home, this Smart Siren will issue a high alarm sound and flash to signal an alarm. Your Smart Home system will simultaneously send push notifications to all connected users to alert you to the alarm situation.

ILLUSTRATION



TECHNICAL PARAMETERS

Working Voltage:
AC100~240V~50Hz/60Hz, 10mA

Backup Battery:
3.7V Li-ion , 720mAh

Alarm Sound Level:
95dB (1 m away)


Networking:
Zigbee 1.2 Home Automation

Operation Temperature:
-10°C~+50°C

Relative Humidity:
≤95%RH (no condensation)

Dimension:
φ80mm x H32mm (Plug not included)

STEP 1




Insert the Smart Siren into a socket to power it on.

*Choose the correct adapter for your requirement.


STEP 2



Click on the gear-symbol on your dashboard to add new device. Start device scan to search for new device.



STEP 3



Add to gateway:

After starting the search in the APP, press network button (pin hole) for 3 seconds to enter inclusion mode. LED will flash rapidly until device are detected by your gateway, you will see the new device appear in the search results on your app.

Disconnect:

Press and hold the network button (pin hole) for 5 seconds to disconnect / reset the device. The LED will flash six times to indicate successfully disconnected / reset.

BACKUP BATTERY

After power off, the backup battery will start to work for 4 hours continuously and issue alarm signals for 5 minutes.

Statements:

* The illustrations are for reference only.

* As the technology is constantly updated, if the instructions and the actual operation is inconsistent, the final interpretation is owned by the company herein.